

D-207BN

TYPE: 1.5" Non-Overflow Grid Bathroom Sink Drain

FINISH: Brushed Nickel

STANDARD INSTALLATION

1. Separate all mounting hardware as shown.
2. Place a bead of plumbers putty or silicone under the drain rim #1.
3. Put drain #1 directly into the drain opening of the sink.
4. From underneath the sink slide the rubber gasket #2, metal retaining ring #3 and the lock nut #4, onto the threaded seat #1 and tighten into position.
5. Wrap the threads on the tail pipe #5 with teflon tape.
6. Install tail pipe #5 into the bottom seat #1.
7. Be sure to trim away excess silicone or plumbers putty from the top of the seat #1 after drain is installed.
8. Protect with spray wax protectant (W900-WAX).

CARE & CLEANING INSTRUCTIONS

- Do not use alkaline, acid based detergents, abrasive polishes, scouring cleansers, S.O.S. Pads or scotch brite pads when cleaning your decorative lavatory drains.
- Do not leave corrosive chemicals or solids laying in the bottom of the sink basin, such as coffee grounds, vinegar, etc.
- After normal use, always wipe the exposed surface area of your drain with a clean soft cloth. This will aid in limiting water spots.
- For normal cleaning, just wipe with a damp cloth and dry with a soft cloth.
- If a chemical cleaner is required when cleaning, windex or a mild dish washing soap can be used.

MORE INFORMATION



YOUTUBE



WEBSITE

SUGGESTED ACCESSORIES

W900-WAX

Spray Wax Protectant

