

# D-208ORB

**TYPE:** 1.5" Non-Overflow Pop-up Bathroom Sink Drain

**FINISH:** Oil Rubbed Bronze

## STANDARD INSTALLATION

1. Separate all mounting hardware as shown.
2. Place a bead of plumbers putty or silicone (C900-ORB) under the drain rim #1.
3. Put drain #1 directly into the drain opening of the sink.
4. From underneath the sink, slide the rubber gasket #2 up. Slide paper gasket #3 into place where the drain and sink meet.
5. Hand tighten the lock nut #4. DO NOT OVER TIGHTEN.
6. Insert the sealing washer #5 into the recess of nut #6.
7. Install tail pipe #7 into the bottom of seat #1 by tightening the #6 nut.
8. Be sure to trim away excess silicone or plumbers putty from the top of the seat #1 after drain is installed.
9. Protect with spray wax protectant (W900-WAX).

## CARE & CLEANING INSTRUCTIONS

- Do not use alkaline, acid based detergents, abrasive polishes, scouring cleansers, S.O.S. Pads or scotch brite pads when cleaning your decorative lavatory drains.
- Do not leave corrosive chemicals or solids laying in the bottom of the sink basin, such as coffee grounds, vinegar, etc.
- After normal use, always wipe the exposed surface area of your drain with a clean soft cloth. This will aid in limiting water spots.
- For normal cleaning, just wipe with a damp cloth and dry with a soft cloth.
- If a chemical cleaner is required when cleaning, windex or a mild dish washing soap can be used.

## MORE INFORMATION



YOUTUBE



WEBSITE

INFO@PREMIERCOPPERPRODUCTS.COM | PREMIERCOPPERPRODUCTS.COM  
425 E. PINNACLE PEAK RD. STE 170, PHOENIX, AZ 85024 | (602) 476-7332

## SUGGESTED ACCESSORIES

C900-ORB

Copper Sink  
Installation Silicone



W900-WAX

Spray Wax Protectant

