

D-133ORB

TYPE: 2" Bar Basket Strainer Drain

FINISH: Oil Rubbed Bronze

STANDARD INSTALLATION

1. Separate all mounting hardware as shown.
2. Apply plumbers putty or silicone (C900-ORB) to the underside of strainer body flange #3.
3. Place the strainer body #3 into sink hole.
4. Place rubber seal #4 onto the top of the plastic tailpiece #5.
5. Place tightening screw #2 through the center of the top of the strainer body #3.
6. Holding the plastic tailpiece #5 from below the sink, hand tighten the screw #2 through the strainer body #3 and into the plastic tailpiece #5. Make sure that you tighten an additional ¼ turn after hand tightened.
7. Lubricate post on bottom of strainer basket #1 with liquid soap, then place strainer basket #1 into strainer body #3.
8. Attached flanged drain pipe (not shown) through nut #7 and seal washer #6, then hand tighten nut #7 to the bottom of plastic tailpiece #5.
9. Protect with spray wax protectant (W900-WAX).

CARE & CLEANING INSTRUCTIONS

- Do not use alkaline, acid based detergents, abrasive polishes, scouring cleansers, S.O.S. Pads or scotch brite pads when cleaning your decorative lavatory drains.
- Do not leave corrosive chemicals or solids laying in the bottom of the sink basin, such as coffee grounds, vinegar, etc.
- After normal use, always wipe the exposed surface area of your drain with a clean soft cloth. This will aid in limiting water spots.
- For normal cleaning, just wipe with a damp cloth and dry with a soft cloth.
- If a chemical cleaner is required when cleaning, windex or a mild dish washing soap can be used.

MORE INFORMATION



YOUTUBE



WEBSITE

SUGGESTED ACCESSORIES

C900-ORB

Copper Sink
Installation Silicone



W900-WAX

Spray Wax Protectant

