



BATHROOM SINK INSTALLATION INSTRUCTIONS

GENERAL GUIDELINES:

- 1) PREMIER COPPER PRODUCTS RECOMMENDS USING A PROFESSIONAL INSTALLER TO INSTALL OUR PRODUCTS.
- 2) YOU WILL NEED A LARGE PIECE CRAFT OR TRACING PAPER FOR USE WHEN MAKING A TEMPLATE. ALL OF OUR SINKS ARE HANDMADE AND THEREFORE DIMENSION MAY VARY. WE RECOMMEND USING THE ACTUAL SINK TO MAKE THE TEMPLATE FOR THE CUTOUT.
- 3) YOU WILL NEED OUR COPPER SINK INSTALLATION SILICONE (ITEM NUMBER C900-ORB) TO INSTALL THE SINK AND DRAIN PROPERLY. IF YOU DO NOT HAVE OUR SPECIAL COLOR MATCHED NEUTRAL CURE SILICONE YOU CAN USE CLEAR 100% SILICONE (NON-WATER BASED) PURCHASED AT ANY HARDWARE STORE.
- 4) PREMIER COPPER SINK INSTALLATION SILICONE SHOULD BE USED TO INSTALL THE DRAIN IN THE SINK AS WELL. USING PLUMBERS PUTTY WILL CREATE A "BULLS EYE" EFFECT AROUND YOUR DARK DRAIN DUE TO THE WHITE COLOR OF THE PUTTY.
- 5) PLEASE REVIEW THE CARE INSTRUCTIONS THAT CAME WITH YOUR SINK. COPPER CLEANER SHOULD NEVER BE USED ON OUR SINKS, IT WILL STRIP THE PATINA OFF THE SINK. USE ONLY MILD, NON-ANTIBACTERIAL SOAP AND WATER FOR CLEANING.

UNDER MOUNT

- 1) USING A PIECE OF TRACING PAPER, TRACE THE INNER RIM OF THE SINK TO MAKE CUTOUT TEMPLATE.
- 2) CUT OUT THE TRACED LINE AND PLACE IT ON THE SINK TO MAKE SURE THE SIZE IS CORRECT.
- 3) PLACE THE TEMPLATE ON THE COUNTERTOP MAKING SURE TO LEAVE AT LEAST 4" OF SPACE BEHIND THE CUTOUT FOR THE FAUCET. TRACE THE OUTLINE OF THE TEMPLATE ONTO THE COUNTERTOP.
- 4) CUT OUT THE HOLE IN COUNTERTOP.
- 5) APPLY THE COPPER SINK INSTALLATION SILICONE TO THE RIM OF THE SINK TO SEAL WHERE THE SINK MEETS THE COUNTERTOP. PLACE SINK ON UNDERSIDE OF COUNTERTOP AND CLEAN UP EXCESS SILICONE. ALLOW TO DRY FOR 24 HOURS.
- 6) IF NECESSARY, SCREWS AND ANCHORS CAN BE USED TO ANCHOR THE SINK THE BOTTOM OF THE COUNTERTOP. YOU CAN DRILL THE HOLES FOR THE ANCHORS DIRECTLY THROUGH THE RIM OF THE SINK.

SURFACE MOUNT

- 1) TURN THE SINK FACE DOWN ON TOP OF A PIECE OF TRACING OR CRAFT PAPER. USING A PENCIL, TRACE AROUND THE SINK WHERE THE SINK TOUCHES THE PIECE OF PAPER. THIS WILL ALLOW ENOUGH ROOM FOR THE SINK TO DROP INTO THE COUNTERTOP.
- 2) CUT OUT THE TRACED LINE AND PLACE IT ON THE SINK TO MAKE SURE THE SIZE IS CORRECT. IT SHOULD BE SMALLER THAN THE OUTER RIM.
- 3) PLACE THE TEMPLATE ON THE COUNTERTOP MAKING SURE TO LEAVE AT LEAST 4" OF SPACE BEHIND THE CUTOUT FOR THE FAUCET. TRACE THE OUTLINE OF THE TEMPLATE ONTO THE COUNTERTOP.
- 4) CUT OUT THE HOLE IN COUNTERTOP.
- 5) PLACE THE SINK INTO THE CUTOUT HOLE. ALIGN THE SINK IN THE COUNTER AND TRACE THE OUTER RIM SO THAT IT STAYS IN THE CORRECT POSITION. HAVE A SECOND PERSON HOLD THE SINK IN PLACE WHILE YOU RUN A BEAD OF COPPER SINK INSTALLATION SILICONE AROUND THE OUTER RIM. DRAG YOUR FINGER AROUND THE OUTER RIM TO SMOOTH OUT THE SILICONE. ALLOW TO DRY FOR 24 HOURS.
- 6) WIPE ANY EXCESS SILICONE OFF THE COUNTERTOP USING A CLEAN DRY RAG.